

Fleetmasters, LLC Straight Truck Service Report

CUSTOMER _____

UNIT# _____ MILEAGE _____

DATE _____ MECHANIC _____

C=Check A=Adjust R=Repair
All Repairs Must Have Corresponding Repair Order

<u>IN CAB CHECK</u>	C	A	R		C	A	R	<u>Cooling System</u>	C	A	R
LEAKS-BODY CONDITION				Disc Pad Min 3/16"				Radiator Coolant Level			
OIL PRESSURE IDLE ___ FULL RPM				Brakes				Freeze Point _____ Must be < -20			
AUDIO CHECK-UNUSUAL NOISE				FRONT/REAR BRAKES- ADJUSTERS				DCA/SCA Level _____ See Note Below			
WINDSHIELD WIPER-WASHER OP				LININGS Steer axle > 1/4"				Fan Clutch Operation			
HEATER-DEFROSTER-AIR COND.				LININGS Other than Steer > 5/16				Leaks			
SEAT Condition-Operation				Disc Pad Min 3/16"				Fan Belts Loose/ Worn			
HORN-AIR-ELECTRIC				Fill Out Chart with Brake Info				Accessory Drive Brackets and Mounting			
FIRE Extinguisher CHARGE				**CVSA standards will apply for Brake				Radiator and Condenser			
FIRE EXTINGUISHER MOUNT				Check Front Wheel Seals for Leakage				Leaks/Mounting/Damage			
SAFETY REFLECTORS				Check Rear Wheel Seals For Leakage				Check Rad/Cond for Dirty fins			
WINDOW LIFTS- DOOR LATCHES				CONDITION OF DRUMS .120 wear Max				RADIATOR COND. - MOUNT			
MIRRORS- WINDOW GLASS				SLACK ADJUSTERS- CAMS & CHAMBERS (See				Fan Shroud			
LOW Air/Vac PRESSURE Warning Light or				Any Slack Adjuster More than 1/2" Out of				FAN BLADE -HUB-MOUNT BRACKETS			
ACTIVATION PRESSURE				Must Be Reported				Drain and Clean Horton filter			
Hydro Boost Operation (if equipped)				Type 30 Std. Slack Adjustment is 1 1/2"				HOSES AND CLAMPS-CHAFFING-LEAKS			
SEAT BELT OPERATION				Type 16 Std. Slack Adjustment is 1 1/8"				LOWER RADIATOR TANK & HOSE CONN.			
Check Dash Lights/ Dash Operation				Air Hoses routing/chafing							
				Check For Air Leaks Complete Truck							
								UNDER HOOD CHECK			
CHASSIS CHECK				Drain Air Tanks (Notify driver if Excess Water)				CHANGE OIL _____ Qts Added _____			
Steering				SLACK ADJUSTERS- CAMS & CHAMBERS				CHANGE OIL FILTERS			
STEERING BOX TO FRAME BOLTS				Air Hoses routing/chafing				CHANGE FUEL FILTERS			
STEERING ARM- DRAGLINK-Pitman				Air Leaks /Brake Fluid Leaks				Davco Filter is only changed when more than 1/2			
KING PIN- FRONT AXLE				Check Brake Chamber s Leaks Using DOT Procedures				ALT. MOUNT. BRACKET & BOLTS			
TIE ROD ENDS				Grease Brake Cams Bushings				AIR COND. COMP. MOUNT AND WIRE			
TIRE WEAR				Grease Slack Adjusters				AIR COMPRESSOR HOSES AND LINES			
U-BOLT-CENTER BOLT SADDLES				Jack up All Wheel Ends Manually Spin / Check for				WATER PUMP AND OIL COOLER			
STEERING-FREE PLAY-LOOSENESS				End Play or Noise				ALL LINES AND WIRING CONNECTIONS			
FRONT CROSS MEMBER & Frame				Suspension				LUBE CHASSIS			
Power steering Oil Level and Condition				SHACKLES & PINS				LUBE DOOR LATCH & AIR RIDE SEATS			
Power Steering Mounting and Bracket				SHOCK ABSORBER Leaking/Brackets/Mounting				WATER PUMP AND OIL COOLER			
Power steering Leaks				Rear Sway Bars and Bushings				Check HVAC Filters (T2=1) (Columbia=2)			
Grease Steering				Rear Link Arms and Bushings				CHECK ALL BELTS			
				Rear Trunion Control Arm Bushings and Link				Wheels And Tires			
Engine				Check Air Bags Mounts & Lines				TIRE INFLATION / CHECK TIRE SPEC			
UNDERSIDE OF ENGINE LEAKS				Check Air Bag Control Valve				ANY TIRE LOWER THAN 60% AIR PRESSURE MUST BE REPAIRED			
REAR ENG. MOUNT & BELL HSGN.				Check Springs and Radius Arms				TIRE VALVES SHOULD HAVE METAL CAPS			
FRONT ENG. MOUNTS				Grease Suspension				Miss matches > 5/32 must be corrected			
STARTER MOUNT & WIRING				Electrical System				Tire Tread Must exceed 5/32 at Major Tread			
EXHAUST PIPING- BRKTS AND				STARTER OPERATION				Fill Out Tire Chart			
EXHAUST MUFFLER AND STACK				LIGHTS-MAIN (Marker , Cab, Headlight)				Irregular Wear Must be Reported			
CHECK TURBO MOUNT AND LINES				Lights Turn/ 4-Way				Reference New World/ Bridgestone Policy Book			
Check Air Filter				Lights Turn/ 4-Way				Front Wheel Bearing Oil Must be Topped			
Call for Approval Before Replacing				Wiring Harness and Connections				75w140 SYN			
				Chafing/Corrosion/Routing				Check Front Hub Oil for Burning or Metal			
				BATT. CABLES-CORROSION-CHAFFING				Check and inspect all Lug Nuts			
Driveline				Clean battery cables and Connection				Check and Inspect Drive Axle Flange Nuts			
CLUTCH LINKAGE AND BRACKETS				BATTERY BOX /Cover							
TRANSMISSION- LEAKS											
U-JOINT CONDITION BOLTS AND				Cab inspection External				Body Inspection			
DRIVE LINE- PINION BACKLASH &				FUEL TANK and brackets				Interior/Exterior Damage Record on chart			
REAR END-LEAKS				EXTERNAL BODY DAMAGE				Door Seals			
TORQUE ARMS AND BUSHINGS				Check Side Cab Steps and Brackets for cracks				Floor Damage/ Wear			
Clutch Free Play 2 inch Min				Check Side Fairing Panels for Cracks and Mount				Interior lighting			
Clutch Brake Function				Check Cab Air ride for Operation				Roof Integrity Interior/Exterior			
Grease Driveline				REFLECTORS				Door Latches/Locks			
Grease Clutch Linkage											
Clutch Brake Function											
Trans Oil Level Pts _____ Added											

